



BE AWARE OF TV-SCREEN HEIGHT!
Read mounting instructions!

	\varnothing 5mm \varnothing 13/64"	\varnothing 10mm \varnothing 25/64"
		\varnothing 5mm \varnothing 13/64"



Template for drilling
THIN 550

Vogel's Holding BV 2016 © all rights reserved.