























AS0308L



TV STANDS

ASSEMBLY INSTRUCTIONS



A1x4 	A2x6 	A3x6 	A4x2 	A5x4 
A6x2 	A7x4 	A8x1 	A9x1 	A10x2 
A11x1 	A12x1 	A13x1 		
M5x14 (x4) M-A 	M6x14 (x4) M-B 	M8x20 (x4) M-C 	M6x30 (x4) M-D 	M8x30 (x4) M-E 
(x4) M-F 	(x8) M-G 	(x4) M-H 