


Video Wall Mount



CAUTION: DO NOT EXCEED RATED LISTED WEIGHT. SERIOUS INJURY OR PROPERTY DAMAGE MAY OCCUR!

AS0346VF	 200x200/300x300 400x200/400x400 600x400	 70" MAX	
AS0348VF	 200x200/300x300 400x200/400x400 600x400/800x400		

NOTE: Read the entire instruction manual before you start installation and assembly.

WARNING

- Do not begin the installation until you have read and understood all the instructions and warnings contained in this installation sheet. If you have any questions regarding any of the instructions or warnings, please contact your local distributor.
- This mounting bracket was designed to be installed and utilised **ONLY** as specified in this manual. Improper installation of this product may cause damage or serious injury.
- This product should only be installed by someone with good mechanical ability who has basic building experience and fully understands this manual.
- Make sure that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.
- Always use an assistant or mechanical lifting equipment to safely lift and position the equipment.
- Tighten screws firmly, but do not over tighten. Over tightening can cause damage to the items, This greatly reduces their holding power.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

Component Checklist

IMPORTANT: Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, telephone your local distributor for a replacement.



wall plate (x2)
A



connecting piece (x2)
B



adapter bracket (x2)
C



antiskid block (x2)
D



M5x8 (x8)
E



Allen key (x1)
F

Package M




M5x14 (x4)
M-A



M6x14 (x4)
M-B



M6x30 (x4)
M-C



M8x30 (x4)
M-D



M8x50 (x4)
M-E



washer (x4)
M-F



small spacer (x8)
M-G



big spacer (x8)
M-H

Package W



ST6.3x55 (x6)
W-A




concrete anchor (x6)
W-B





D6 washer (x6)
W-C

1. Assembling the Wall Plates with the Connecting Pieces






2. For Solid Brick and Concrete Wall Mounting



Mark the exact location of mounting holes

Drill pilot holes




Screw the wall plate onto the wall

⚠ WARNING



Installers must verify that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.

3. For Video Wall Installation (Mounting space as shown below)

X=length of display Y=height of display






4. Installing the Adapter Brackets




Top of the display

4a For Flat Back Screens



4b. For Bump-out or Recessed Back Screens




Note: Choose the appropriate screws, washers and spacers (if necessary) according to the type of screen.

- Position the adapter brackets as close as possible to the center of the display.
- Screw the adapter brackets onto the display.

! Tighten all screws but do not over tighten.


5. Hooking the Display onto the Wall Plate




Note: Before hooking the display, make sure the knobs are rotated to the unlock position.





- Lift the display carefully and hook the display onto the wall plate. Rotate the knobs to the lock position for secure the display.
- Use the padlock to prevent the display from being stolen. (Padlock is not included)

6. Adjustment




Push the display to left or right to enable fast alignment.






Kickstands provide tilt access for easy cables management and maintenance.

7. Level the Displays




Adjust the display to keep level in vertical and horizontal directions.



Maintenance

- Check that the bracket is secure and safe to use at regular intervals (at least every three months).
- Please contact your distributor if you have any questions.

8. Fixing the Brackets Position with the Antiskid Blocks



Install the both antiskid blocks as close to the adapter brackets as possible.
Tighten screws on the antiskid blocks using an Allen key to prevent display from moving.